

Superseded by TM 11-6660-213-12P, 1 June 1959,
and -35P, 8 June 1959

*SIG 7 & 8 ML-138 TO 31M1-3ML138-4

DEPARTMENT OF THE ARMY SUPPLY MANUAL DEPARTMENT OF THE AIR FORCE TECHNICAL ORDER

Organizational Maintenance Allowances and Field and Depot Maintenance Stockage Guide (Including Fixed Plant Maintenance List)

for

TIME INTERVAL UNIT ML-138

Ref: TM 11-334

Departments of the Army and the Air Force, Washington 25, D. C.,

6 May 1957

Note. This manual reflects the results of physical review of the equipment covered herein (TB SIG 305).

1. A copy of SIG 1 and DA Pam 310-21 should be available to every user of the Signal portion of the Army supply manual.

a. SIG 1 explains the purpose and use of the Signal portion of the Army supply manual.

b. DA Pam 310-21 contains alphabetical and numerical indexes of available manuals in the Signal portion of the Army supply manual.

2. Items marked X under expendability note are expendable within the meaning of AR 735-4; nonexpendable items are marked NX.

3. Dry batteries shown are used with the equipment but are not considered part of the equipment. They will not be preshipped automatically but are to be requisitioned in quantities necessary for the particular organization, in accordance with SB 11-6.

4. A percent symbol (%) indicates the item is authorized for use in the category of maintenance indicated and may be requisitioned when required. Not authorized for stockage.

5. The Federal stock number column lists the 11-digit Federal stock number assigned by the

Cataloging Division, OASD (S&L). In the absence of a Federal Stock Number, the Signal Corps stock number will be used for requisitioning purposes.

6. SIG 7 & 8 ML-138 comprises two parts as follows:

a. *Maintenance Items.* A list of parts for repair and supply facilities.

b. *Basic Issue Items.* A list of component parts showing the quantities of each that comprise a complete operating equipment, including running spares, that is, those spare parts shipped concurrently with the equipment., and accessories.

7. Comments relative to technical data discrepancies in this manual should be forwarded to—

Chief
Logistics Engineering Division
Maintenance Engineering Department
U.S. Army Signal Equipment Support
Agency
FORT MONMOUTH, N. J.
ATTN: SIGFM/ES-ML-1

*This manual supersedes DA Supply Manual SIG 7 & 8 ML-138, 17 September 1954.

Copy 1

PROPERTY OF THE TECHNICAL LIBRARY
DO NOT REMOVE FROM BUILDING

BY ORDER OF THE SECRETARIES OF THE ARMY AND THE AIR FORCE:

MAXWELL D. TAYLOR,
General, United States Army,
Chief of Staff.

OFFICIAL:

HERBERT M. JONES,
Major General, United States Army,
The Adjutant General.

N. F. TWINING,
Chief of Staff, United States Air Force.

OFFICIAL:

J. L. TARR,
Colonel, United States Air Force,
Air Adjutant General.

Distribution:

Active Army:

CNGB
ASA
Tec Svc, DA
Tec Svc Bd
Hq CONARC
CONARC Bd
CONARC Bd Test Sec
Army Air Def Comd
OS Maj Comd
OS Base Comd
Log Comd
MDW
Armies
Corps
Div
US Army Tng Cen
Ft & Cp
Gen & Br Svc Sch
Gen Depots
Sig Sec, Gen Depots
Depots
AH
Mil Med Sup Agency
AFIP
Sp Wpn Comd
AMS
POE (OS)
Trans Terminal Comd
Army Terminals
OS Sup Agencies
PG
Arsenals

Active Army:—Con.

Plants & Works
Sig Fld Maint Shops
Lab
Mil Dist
JBUSMC
Units org under fol TOE:
6-100
6-101
6-200
6-201
6-300
6-301
11-7
11-16
11-57
11-116
11-117
11-127
11-128
11-500
11-557
11-587
11-597
44-12
44-16
44-36
44-101
44-112
44-116
44-201
44-316
44-416

NG: State AG: units—same as Active Army.

USAR: None.

For explanation of abbreviations used, see SR 320-50-1.

☆U.S. GOVERNMENT PRINTING OFFICE: 1957—400799/1511